


Test Weights

All counting scales can be calibrated using the internal software, and a certified test weight. To achieve optimum accuracy from the balance, it should be adjusted in the locality where it is used, because the latitude and longitude affect the calibration and the strain gauge cell could go out of adjustment during the transportation.

8301.300	Test Weight	0.1Kg	F1 class - case - DKD certificate
8301.303	Test Weight	0.5Kg	F1 class - case - DKD certificate
8301.305	Test Weight	1Kg	F1 class - case - DKD certificate
8301.310	Test Weight	2Kg	F1 class - case - DKD certificate
8301.315	Test Weight	10Kg	F1 class - case - DKD certificate



Utility Software




County

County-S

County-W

Software to interface all the County models to the serial port of a PC

With this free software it's possible to write the counted pieces of your County to almost every Windows application. It's also possible to make tables with Code, Quantity, Date and Time using a barcode reader.



License: Freeware
S.O.: Windows 95/98/ME/NT/2000/XP
File size: 50Kb

TRACTOR


TRACTOR depaneling machine separates the prescored PCB, in a very quick and economic way.

The compact and stable aluminium frame requires a minimum space.

The assembled PCB panel is shoved between the circular blades and is thereby separated.

The circular blades and guides are made of special steel to ensure a long time life.

The hand model is suggested only for small productions and prototype series.



Separation length:
Thickness of panels:
Maximum components' height:

up to 350mm
0.8 - 3.2mm
34 - 43mm

7915.580
7915.582
7915.584

TRACTOR - PCB Hand depaneling machine
TRACTOR - PCB Motorized depaneling machine 220VAC
TRACTOR - PCB Motorized depaneling machine 110VAC